



9. To determine the wavelength of laser light using single slit diffraction pattern.

Position of detector (mm)	Power in terms of current (μA)
-5.00	0.0
-4.37	0.1
-4.15	0.3
-3.84	0.4
-3.48	0.5
-2.91	0.3
-2.78	0.2
-2.66	0.1
-2.40	0.0
-2.11	0.1
-1.99	0.4
-1.64	0.7
-1.31	3.5
-1.03	5.2
-0.74	7.7
-0.42	10.4
0.00	11.3
0.15	11.7
0.44	11.4
0.74	10.0
0.95	8.1
1.15	6.6
1.55	2.7
1.89	1.5
2.14	0.5
2.53	0.0
2.97	0.1
3.12	0.3
3.25	0.5
3.50	0.7
3.90	0.8
4.26	0.6
4.65	0.3
5.12	0.1
5.55	0.0



For Slit width (d):

Left Position (mm)	Right Position (mm)	d (mm)
8.85	8.57	0.28
8.88	8.58	0.30
8.85	8.56	0.29

Observation

$d = 0.29 \text{ mm}$, LC: 0.01 mm
 $D = 1090 \text{ mm}$, LC: 1 mm
 $2L = 2.53 - (-2.4) = 4.93 \text{ mm}$, LC: 0.01 mm
 $\Delta\theta_{\pm 1} = 0.0045$

$$\Delta\theta_{\pm 1} = \frac{2L}{D} \quad \Rightarrow \quad \Delta\theta_{\pm 1} = \theta_1 - \theta_{-1} = \frac{2\lambda}{d}$$

Calculated Wavelength = 652 nm

Error Analysis

The angular separation is defined as:

$$\Delta\theta_{\pm 1} = \frac{2L}{D} \quad \dots\dots (1)$$

Also,

$$\Delta\theta_{\pm 1} = \frac{2\lambda}{d} \quad \dots\dots (2)$$

From (1) & (2)

$$\lambda = \frac{d \times L}{D}$$

Calculation of log error in wavelength (λ) is given by:

$$\log(\lambda) = \log(d) + \log(L) + \log(D)$$

$$\frac{d\lambda}{\lambda} = \frac{dd}{d} + \frac{dL}{L} + \frac{dD}{D}$$

Here, $dd = 0.01$, $dL = 0.01$, $dD = 1$

$$\frac{d\lambda}{\lambda} = \frac{dd}{d} + \frac{dL}{L} + \frac{dD}{D}$$

$$\frac{d\lambda}{\lambda} = \frac{0.01}{0.29} + \frac{0.01}{2.46} + \frac{1}{1090}$$

$$\frac{d\lambda}{\lambda} = 0.0389$$

$$d\lambda = \lambda \times 0.0389 = 652 \times 0.0389 = 25.36 \text{ nm.} \quad (\text{Calculated error in wavelength})$$

$$\lambda = 650 \pm 30 \text{ nm}$$